

Thank you for purchasing this instrument from Intellitronix. We value our customers!

## INSTALLATION GUIDE TACHOMETER Recall Kit Part Number: N4026

\* Always disconnect the battery *before* attempting any electrical work on your vehicle.\*

## WIRING INSTRUCTIONS

*Note: Automotive circuit connectors are the preferred method of connecting wires. However, you may solder if you prefer.* 

*Power* - **Red** Connect to a switched +12V source.

Ground - Black Connect to the engine block ground.


\*Tach Input - Grey Connect to the negative terminal of your coil.

Tach Output - Green Connect to the input of your tachometer gauge.

**\*Note:** If you are using a capacitive discharge system such as an MSD, you must not make any connections directly to the coil. Instead, you must use the "Tach Output" from the MSD box.

## **OPERATION**

- ◊ Pressing the switch at any time will recall the highest RPM and display it on your tachometer gauge.
- $\Diamond$  Holding the switch for at least five seconds will reset the saved RPM.
- ◊ The Tachometer Recall Kit will retain your highest RPM until +12V power is lost to the circuit or until manually reset.





**Technical Support** 

Monday – Friday 9am to 5 pm EST

(440) 210-7646 support@intellitronix.com



This product carries a limited Lifetime Warranty. This warranty is limited to replacement or repair of the unit at the discretion of Intellitronix.